



Cisco Unified Communications Manager SIP Line Messaging Guide (Standard)

This document applies to Cisco Unified Communications Manager Release 7.1(3).

Americas Headquarters

Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA

http://www.cisco.com Tel: 408 526-4000

800 553-NETS (6387)

Fax: 408 527-0883

Text Part Number: OL-19995-01

These materials are made available by Cisco as a courtesy to provide certain Session Initiation Protocol (SIP) interoperability information. All information is provided "as is" and Cisco disclaims all express or implied warranties regarding these materials. Cisco is not liable for the accuracy or completeness of these materials.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCDE, CCENT, CCSI, Cisco Eos, Cisco HealthPresence, Cisco IronPort, the Cisco logo, Cisco Lumin, Cisco Nexus, Cisco Nurse Connect, Cisco Pulse, Cisco StackPower, Cisco StadiumVision, Cisco TelePresence, Cisco Unified Computing System, Cisco WebEx, DCE, Flip Channels, Flip for Good, Flip Mino, Flipshare (Design), Flip Ultra, Flip Video, Flip Video (Design), Instant Broadband, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn, Cisco Capital, Cisco Capital (Design), Cisco:Financed (Stylized), Cisco Store, and Flip Gift Card are service marks; and Access Registrar, Aironet, AllTouch, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, Continuum, EtherFast, EtherSwitch, Event Center, Explorer, Fast Step, Follow Me Browsing, FormShare, GainMaker, GigaDrive, HomeLink, iLYNX, Internet Quotient, IOS, iPhone, iQuick Study, IronPort, the IronPort logo, Laser Link, LightStream, Linksys, MediaTone, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, Network Registrar, PCNow, PIX, PowerKEY, PowerPanels, PowerTV, PowerTV (Design), PowerVu, Prisma, ProConnect, ROSA, ScriptShare, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0908R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

Cisco Unified Communications Manager SIP Line Messaging Guide (Standard), Release 7.1(3) Copyright © 2006-2009, Cisco Systems, Inc. All rights reserved.



CONTENTS

Preface v

Audience v

Organization

Conventions vi

Obtaining Documentation, Obtaining Support, and Security Guidelines vii

CHAPTER 1

SIP Standard Line Interface 1-1

New and Changed Information 1-1

Contents



Preface

This document is an addendum and describes the major interface changes to Cisco Unified Communications Manager (Unified CM) Session Initiation Protocol (SIP) line side devices that were introduced between Unified CM 7.0 and 7.1(3).



This chapter describes the new features and callflows added to Unfied CM 7.1(3). Since no new SIP Line (Std) feature is released with Cisco Unified CM 7.1(3); it is recommended that you view the complete list of exisiting SIP basic call flows from SIP Line Messaging Guide (Standard) for Release 7.0(1) and SIP Line Messaging Guide (Standard) for Release 7.1(2) from:

http://www.cisco.com/en/US/products/sw/voicesw/ps556/products_programming_reference_guides_list.html

The preface covers these topics:

- Audience
- Organization
- Conventions
- Obtaining Documentation, Obtaining Support, and Security Guidelines

Audience

This document provides information for developers, vendors, and customers who are developing applications or products that integrate with Cisco Unified Communications Manager using SIP messaging.

Organization

This document consists of the following two chapters.

Chapter	Description
	Provides an overview of SIP line messages, new and changed information and standard features scenarios including sequence chart and example of call lfows added in this release.

Conventions

This document uses the following conventions:

Convention	Description
boldface font	Commands and keywords are in boldface .
italic font	Arguments for which you supply values are in italics.
[]	Elements in square brackets are optional.
{ x y z }	Alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
screen font	Terminal sessions and information the system displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font.
italic screen font	Arguments for which you supply values are in <i>italic screen</i> font.
\rightarrow	This pointer highlights an important line of text in an example.
٨	The symbol ^ represents the key labeled Control—for example, the key combination ^D in a screen display means hold down the Control key while you press the D key.
< >	Nonprinting characters, such as passwords are in angle brackets.

Notes use the following conventions:



Note

Means reader take note. Notes contain helpful suggestions or references to material not covered in the publication.



Means reader be careful. In this situation, you might do something that could result in equipment damage or loss of data.



Means the following information might help you solve a problem.



Means the described action saves time. You can save time by performing the action described in the paragraph.

Obtaining Documentation, Obtaining Support, and Security Guidelines

For information on obtaining documentation, obtaining support, providing documentation feedback, security guidelines, and also recommended aliases and general Cisco documents, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html



₽ CHAPTER

SIP Standard Line Interface

This chapter describes the external interface for Cisco Unified CM SIP line-side devices. It highlights SIP primitives that are supported on the line-side interface and describes call flow scenarios that can be used as a guide for technical support and future development.

This guide is applicable to CiscoUnified CM 7.1(3) and covers only those elements that have changed/newly added from the previous version (Cisco Unified CM 7.0).



This chapter describes the new features and callflows added to Unfied CM 7.1(3). Since no new SIP Line (Std) feature is released with Cisco Unified CM 7.1(3); it is recommended that you view the complete list of exisiting SIP basic call flows from SIP Line Messaging Guide (Standard) for Release 7.0(1) and SIP Line Messaging Guide (Standard) for Release 7.1(2) from:

http://www.cisco.com/en/US/products/sw/voicesw/ps556/products_programming_reference_guides_list.html

This chapter includes these sections:

• New and Changed Information, page 1-1

New and Changed Information

This release of Unified CM 7.1(3) does not introduce any new features to the SIP Standard Line Interface.

New and Changed Information